



Installation Instructions  
**MOPAR SHORT THROW SHIFT LEVER AND KNOB**  
2009 and up Dodge Challenger  
PART NUMBER P5155284AB

---

### MOPAR PERFORMANCE PARTS WARRANTY

Mopar Performance parts beginning with a “P” prefix sold by Mopar Performance carry no warranty whatsoever. **Implied warranties, such as warranties of merchantability, are excluded.** (An implied warranty of merchantability means that the part is reasonably fit for the general purpose for which it was sold). The entire risk as to quality and performance of such parts is with the buyer. Should such parts prove defective following their purchase, the buyer and not the manufacturer, distributor or retailer, assumes the entire cost of all necessary servicing or repair. Chrysler, Dodge, and Jeep vehicle and parts warranties are voided if the vehicle or parts are used for competition. The addition of performance parts does not by itself void a vehicle’s warranty. However, added performance parts (parts not originally supplied on the vehicle from the factory) are not covered by the vehicle’s warranty, and any failure that they may cause is also not covered by the vehicle’s warranty.

*For technical assistance regarding this product, please contact the Direct Connection Tech Line Monday-Friday, 9:00 A.M.– 5:00 P.M. EST at 1(888) 528-HEMI or 1(888) 524-4364*

## REMOVAL

1. Gently pry trim bezel from console using a trim stick (Mopar tool number C-4755 or equivalent). Remove the shift lever bezel as shown.



2. Remove the shift lever bolts and the shift lever.





Installation Instructions  
**MOPAR SHORT THROW SHIFT LEVER AND KNOB**  
2009 and up Dodge Challenger  
PART NUMBER P5155284AB

---

## ASSEMBLY

3. Using the trim stick separate the shifter boot from the shift lever.



4. Turn boot inside out. Slide over ferrule on the Mopar® shifter assembly until the end of the boot is in line with the bottom edge (with the flats) of the ferrule.



5. Secure tightly with tie wrap making sure to position it in the groove between the collar and the bottom edge of the ferrule.



6. Reinstall shift lever into shifter assembly. Reinstall shift lever mounting bolts into shifter assembly. Tighten the bolts to 20 N•m ( 15 ft. lbs.) . Snap bezel back in place.

